Nexus 5 SIM Card Replacement

Replace your Nexus 5 SIM card.

Written By: Kyle Libby



INTRODUCTION

This guide will show you how to replace your Nexus 5 SIM card.

TOOLS:

- SIM Card Eject Tool (1)

PARTS:

- Nexus 5 SIM Card Tray (1)

Step 1 — SIM Card





- Insert a SIM card eject tool or a paper clip into the hole next to the SIM card slot, which is located just under the power button.
- Push the tool into the hole until you see the card pop out.

Step 2



- Gently remove the SIM card with your fingers, or a pair of tweezers if the SIM holder does not fully eject.
- Make sure the chip is facing the rear of the phone when reinserting the SIM card.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 06:23:23 AM.